

Encompass

Shower Bases



SHOWER BASE CLEANING AND CARE

Your Encompass Shower Base™ is made of solid surface material produced from a natural mineral and acrylic polymer. This material is nonporous and the color runs throughout the thickness of the material which makes it very durable, easy to clean, and long lasting. By following the recommendations below, the performance and beauty of the product will be preserved for years of trouble free service.

Daily: Rinse the surface with warm water following use to help prevent soap scum buildup. Soap Scum build up can make any surface slippery. Hard water can cause mineral build up and spotting especially with dark colors. Do hard rinse after use to control buildup.

General Cleaning: Always use eye protection and gloves when using cleaning products. Most dirt and residue can be cleaned with standard nonabrasive household liquid cleaners such as Mr. Clean™, Top Job™, Lysol Mr. Bubbles™, or similar products. Routinely clean Drain Channel and Stainless Steel Strainer. Do not allow cleaning products to remain on base or drain area for an extended period of time and never let dry. Flush base and drain area thoroughly after cleaning.

Note: If any of the cleaning products you purchase contain bleach or ammonia as an additional cleaner, remember these two products are highly toxic when mixed together so be extra careful when using either of these so NOT to accidentally use them together. This combination can create a serious health risk and in some cases can be fatal.

Difficult Residue: To remove hard water stains or mineral build up, use CLR™, Lime Away™, or similar products. Read and follow each manufacturer instructions and precautions for use. Do not use any cleaning products not intended for use on acrylic or plastics or that contain acid or high alkaline content such as Drain Cleaners. If these products should come in contact with the base surface, rinse thoroughly or the chemical may cause damage.

Surface Stains or Scratches: For surface stains use an abrasive cleaner such as Ajax™ or Comet™ with a Green or Maroon Scotchbrite™ Scouring Pad by 3M™. If necessary, use 100 grit sandpaper to remove minor scratches. Scrub or sand a larger area than the scratch to prevent a low spot. Seek the help of a professional to remove deep scratches. Do **NOT** apply waxes or topical products as they may build up and cause cleaning issues and negatively affect the surface performance of the base.



Encompass Shower Bases
Meet HUD Bulletin 73a, CSA B45/IAMPO Z124.1.2
ICC/ANSI A117.1, ASTM 462
Standards



KITCHEN AND BATH
7540 S. Grant St.
Littleton, CO 80122
Phone (303) 347-1345
Fax (303) 347-0992
www.sanderandsons.com